



General Description

The LD135 is a long life silver/silver chloride reference electrode with a stable reference potential specifically for permanent installation. The essential components are silver metal, silver chloride, soluble silver ions and chloride ions.

A sparingly soluble salt, silver chloride, is in equilibrium with a saturated solution of this salt which precipitates in the course of electrolysis. The reversible electrode reaction consists of silver ions going into solution and then combining with the chloride ions to form silver chloride. Thus its potential is determined by the following reactions:

$$Ag <> Ag + e^{-}$$

$$Ag^+ + Cl^- <> AgCl(s)$$

$$Ag + Cl^- <> AgCl(s) + e^-$$

The potential is dependent on temperature and the concentration of chloride ions in accordance with the following equation:

$$E=E_0 \frac{RT}{F} \ln [Cl^-]$$

Where E_0 , R, F and T are the standard potential, gas constant, Faraday Constant and temperature respectively. The reaction has been proved to obey these equations in solutions with pH's of between 0 and 13.5. The potential is however very sensitive to traces of bromide ions which make it more negative.

The electrode element has been prepared by electrolytic precipitation of silver chloride onto silver metal. This has then been embedded in a mortar containing a known concentration of chloride ions and an anti-drying agent. The housing consists of a white nylon barrel, white nylon inserts, cable gland rated at IP68 and porous ceramic junctions separating the mortar from the external environment at the measuring interfaces.

Specification

Element Type: Ag, AgCI(s), CI-, Ag+

Typical 3g silver per electrode

Potential: -15Mv +/-10Mv versus the Saturated Calomel Electrode (SCE)

230Mv +/-10mV versus the Standard Hydrogen Electrode (SHE)

Drift: less 3mV in 24 hours.

Typically less than +/-10mV expected in 20 years

Note: The potential drift is subject to temperature, Donnan potential and liquid junction potential changes within the surrounding environment which

may mask any changes produced by the electrode itself.

Internal Resistance: Less than 2kOhms

Polarisation Characteristics (determined galvanostatically in calcium hydroxide solution)

2mV potential shift after the application of $0.1\mu A$ for 30 seconds. 12mV potential shift after the application of $1\mu A$ for 30 seconds.

Dimensions: 135 mm long x 26mm diameter

Cable gland 20mm long x 15mm diameter

Housing: White Nylon Barrel

White Nylon Insert Cable Gland IP68

Ceramic junction measuring interfaces: End sensor 1 x 19mm diameter

Circumferential 3 x 7mm diameter.

Cable: Supplied to order





Expected life: More than 57 years at a leakage current of $1\mu A$ will result in the loss of

2 grams of silver. The functional life of the electrode will most likely to

be determined by the life of the associated cables.

Other Features: Large Measuring Interface (400mm²)

Anti Drying Agent

Installation Procedures

The purpose of this statement is to ensure that the reference electrodes when delivered to site are correctly stored, checked for functionality and installed.

Storage

The electrodes are individually numbered and delivered to site boxed with the red protective caps in place. The purpose of the caps is to protect the sensor end of the electrode from contamination or damage whilst in storage. With the delivery inside the box there will be a calibration certificate for all the delivered electrodes. This document should be kept with the record documents for the contract. The calibration certificate is a record of the individual reference potentials measured against a saturated calomel electrode (SCE) at 20°C under laboratory conditions. The Corrosion Engineer may refer to the information on the calibration certificate during the operation of the monitoring system.

The electrodes should be checked to ensure that they match the order and stored with the red caps in place in a safe, dry place within a temperature range of 0°C and 45°C. It is important to ensure that the electrode and its cable are protected from physical damage.

Pre - installation Functional Check

The purpose of this procedure is to check that the electrode potential is stable. Prepare a solution of 3% salt solution; 30g of sodium chloride (salt) per 1 Lt of water. Remove the cap from the electrode and soak the tip of the electrode in the solution for a **minimum of 2 hours** and **maximum of 3 hours**.

After soaking the electrode measure the potential using a calomel electrode (SCE) with a digital voltmeter at 10mohm and 1000mohm input impedance with the SCE connected to the positive/common terminal and record the results. The potentials should be steady and in the range \pm 20mv of the calibrated values.

A satisfactory alternative to using a saturated calomel electrode would be to check the soaking electrode potentials against each other or use one extra electrode as a test electrode. Once the electrode is checked it should be removed from the solution, the cap carefully replaced and it should be installed within 48 hours.

Copyright © 2006 [Castle Electrodes]. All rights reserved.

Phone: (+44) 01488 608539 Fax: 0870 705 9689 Email: mail@castle-electrodes.com